



FIRST GLASS ROOFS
LIGHT INSPIRED DESIGN

Installation Instructions

Frameless Flat Rooflight

Check the item list to make sure you have all the parts to carry out the installation for the frameless flat rooflight, If you have any of the parts missing please contact the manufactures for advice.

- ✓ Cordless screwdriver
 - ✓ Stanley knife
 - ✓ Glass suckers x 4
 - ✓ Sealant gun
 - ✓ Sealant for application
-
- Un-package the Rooflight by removing the protective corners.

 - Check the upstand is between 3 – 5 degrees and is clean ready for the sealant to be applied.

 - Apply a bead of sealant around the top edge of the up-stand, make sure the bead of sealant is 10 -12mm high and runs all the way around.

 - Lower the roof-light over the upstand into position and press down firmly making sure there is a good adhesion all the way around.

 - Once you are happy with its position bend the internal straps down and fasten into position with screws.

PLEASE NOTE: The sealant used for sealing the Rooflight to the upstand needs to be compatible with the roofing substrate.

Check the item list to make sure you have all the parts to carry out the installation for the frameless flat rooflight, If you have any of the parts missing please contact the manufactures for advice.

Head Office

First Glass Roofs Ltd
Unit 2E Blacknest Industrial Estate
Blacknest, Alton
Hampshire
GU34 4PX

Factory

First Glass Roofs Ltd
Unit 5G Blacknest Industrial Estate
Blacknest, Alton
Hampshire
GU34 4PX