

Installation Instructions Opening Rooflight

Check the item list to make sure you have all the parts to carry out the installation for the Opening Rooflight, If you have any of the parts missing please contact the manufactures for advice.

- ✓ Cordless screwdriver
 - ✓ Stanley knife
 - ✓ Glass suckers x 4
 - ✓ Sealant gun
 - ✓ Sealant for application
 - ✓ Woodscrews
-
- Un-package the Rooflight by removing the protective corners.
 - Check the upstand is between 3 – 5 degrees and is clean ready for the sealant to be applied.
 - Apply a bead of sealant around the top edge of the up-stand, make sure the bead of sealant is 10 -12mm high and runs all the way around.
 - Lower the roof-light over the upstand into position and press down firmly making sure there is a good adhesion all the way around.
 - Once you are happy with its position, fasten the screws through the metal lip into the upstand as shown in the picture.

PLEASE NOTE:

The sealant used for sealing the Rooflight to the upstand needs to be compatible with the roofing substrate.

A qualified Electrician will be required to connect the motor and transformer switch. Wiring diagrams will be provided with every Rooflight.

